



SPARES FOR ROYAL ENFIELD AND AMAL

EMAIL: info@hitchcocksmotorcycles.com

WEB: www.hitchcocksmotorcycles.com

HITCHCOCK'S MOTORCYCLES LTD
ROSEMARY COURT
OLDWICH LANE WEST
CHADWICK END
SOLIHULL
B93 0EY ENGLAND

TELEPHONE: 01564 783 192

FAX: 01564 783 313

Fixing Instructions for: Dual Seat Fixing Kit (Classic EFI C5 Models) – 91441C & 91442C

These are the items you will have received in your kit:

- 1 Dual Seat
- 1 Front Seat Bracket (T Piece Frame)
- 2 Front Seat Brackets
- 1 Middle Seat Bracket (Short)
- 1 Rear Seat Bracket
- 4 Rubber Spacers – Self Adhesive
- 8 Bolts M8 x 20 mm
- 8 Flat Washers 5/16"
- 1 Socket Screw (Button Head) M10
- 1 Serrated Washer 10mm
- 2 Shouldered Spacers
- 2 Q Clips
- 2 Nyloc Nuts M8



This seat and fitting kit are designed to be fully adjustable to take into account slight manufacturing variations between the same models. On some models you may be required to drill a hole through the top of the front bracket on the frame to accommodate the front seat bracket (T piece frame) component


You will require the following tools:


- Allen Key No 6
- 3/8 Spanner
- 13 and 18 Spanner (Metric)
- Pliers / Mole Grips

Instructions:

Remove the existing seat. Retain the nuts and bolts for refitting the new seat later.

Firmly secure the front seat bracket (T piece frame) to the forward seat frame lug on the bike using the serrated washer 10mm and the socket screw (button head) M10. (In some cases you may need to drill the front bracket through the top if required to accommodate this bracket).






Place the new seat upside down on a protective surface (SEE PHOTO LEFT)
 Using the M8 x 20mm bolts and 5/16" flat washers (for all 3 brackets) take the 2 Front Seat Brackets and secure hand tight to the front of seat with the brackets (forks facing front).

Take the Middle Seat Bracket (Short) and secure hand tight to the middle of the seat (curve in bracket should mirror curve under seat, tabs facing front).

Take Rear Seat Bracket and secure hand tight to rear of seat with tabs facing rear. All brackets should now be in place on the seat.


Take the 2 Rear Seat Q Brackets and secure to rear of bike by attaching to the rail on the mudguard (to align with bracket under seat (SEE PHOTO BELOW RIGHT). Once you have pushed the Q clip bracket over the rail, crimp onto the rail using mole grips/pliers (Protect the paint using a cloth)

Offer the seat up to the motorcycle locating the front brackets (with the U shaped forks) onto the front seat bracket (T Piece frame) which you fitted earlier to the bike. Holding the seat at a 45 degree angle will assist with this. Once located, lower the seat down and adjust the middle and rear brackets to line up with the locating points on the frame (including the rear seat Q brackets you have just attached to the bike – use the 2 6mm Nyloc Nuts and Washers to secure when finally fitting). Use the shouldered spacers for the middle bracket (SEE PHOTO BELOW)



Once you are satisfied with the final fit remove the seat and tighten all brackets on the underside of the seat.

Position 2 of the rubber self-adhesive spacers onto the middle seat bracket so that they line up with the top curve of the mudguard. The remaining two are fitted onto the bottom of the two u shaped forks on the front seat mounting brackets (SEE PHOTO BELOW) to provide a cushion between the seat and the frame



Finally re-fit and secure the seat to the bike using the original nuts and bolts

Check all nuts are tight and saddle is now secured in place