



**SPARES for ROYAL ENFIELD & AMAL**

EMAIL: [info@hitchcocksmotorcycles.com](mailto:info@hitchcocksmotorcycles.com)  
WEB: [www.hitchcocksmotorcycles.com](http://www.hitchcocksmotorcycles.com)

**HITCHCOCK'S MOTORCYCLES LTD  
ROSEMARY COURT  
OLDWICH LANE WEST  
CHADWICK END  
SOLIHULL  
B93 0EY ENGLAND**

**TELEPHONE: 01564 783 192  
FAX: 01564 783 313**

## **FITTING INSTRUCTIONS FOR 92647 REARSET KIT**

Parts included in this kit are as follows:

- A. Kick-start lever complete
- B. Brake rod with split pin
- C. Gear pedal with folding footrest and rubbers
- D. Brake pedal with folding footrest and rubbers
- E. Gear lever arm and bolt (gearbox)
- F. Gear link rod with ends
- G. Brake pedal stop bracket and switch assembly
- H. Rear brake cable, cable stop and bracket
- I. Footrest / Silencer Bracket

### **View of Brake Lever Side**

Assemble the Footrest / Silencer Bracket onto the frame. Fit the cone shaped pillar into the tapered hole on the frame where the original footrest was fitted and hold in place with 6mm counter sunk screw ( as per picture ).

Fit the footrest and brake pedal bolts.

The brake pedal stop bracket and switch assembly bolts through the threaded hole on the Footrest / Silencer Bracket.

The cable stop bolts through the rear brake cross-over shaft lug. This is attached with the barrel nut with the large washer on the inside face of the frame lug.



## View of Gear Lever Side

The gear lever pedal bolts through frame lug for the pillion footrest

For the best gear change operation ensure the angle between the lever on the gear box and the link rod is 90 degrees



## View of Brake Lever Side

The rear brake cable bracket is secured with the rear brake plate torque bolt.

